

USAGE

IF YOU HAVE A COCKRING WITH A VIBRATION THEN SWITCH IT ON AND OFF BY SIMPLY PRESSING THE BUTTON. IT HAS ONE VIBRATION MODE.

PLACE THE RING ON THE BASE OF THE ERECT PENIS AND UNDER THE SCROTUM AT THE SAME TIME, STRETCHING THE RING AND PUSHING IT ALONG THE PENIS. THE RING SHOULD BE CONVENIENTLY FIXED WITHOUT ROLLING DOWN AND NOT SQUEEZING THE SCROTUM. IF YOU FEEL DISCOMFORT WHILE USING THE COCK RING - IMMEDIATELY STOP FRICTIONS AND REMOVE IT.

IT IS IMPORTANT NOT TO USE THE RING FOR MORE THAN 30 MINUTES TO AVOID CIRCULATORY DISORDERS.

STORAGE

KEEP THE TOY OUT OF THE REACH OF CHILDREN AND DIRECT SUNLIGHT.

CARE

BEFORE THE FIRST USE, AS WELL AS BEFORE AND AFTER EACH USE, RINSE THE TOY UNDER A WARM STREAM OF WATER (IF THE RING DOESN'T CONTAIN VIBRATION), DRYING WITH A PAPER TOWEL. TREAT THE STIMULATOR WITH A SPECIAL TOY-CLINER FOR ADDITIONAL CARE

MANUAL

Rings!