

USAGE

1. MOVE TO A POSITION THAT IS CONVENIENT FOR YOU
2. GENTLY AND SLOWLY INSERT THE BALL INTO THE VAGINA. IF THERE ARE SEVERAL BALLS, MAKE SURE THAT THE FIRST ONE DOES NOT CAUSE DISCOMFORT BEFORE INSERTING SUBSEQUENT ONES.
3. THE STRING THAT IS ATTACHED TO THE BALL, IF THERE IS ONE, SHOULD REMAIN OUTSIDE FOR COMFORTABLE EXTRACTION.
4. IF YOU FEEL THAT THE BALLS ARE ABOUT TO FALL OUT, PUSH THEM A LITTLE DEEPER.
5. TO EXTRACT THE BALLS, PULL THE SILICONE STRING AT THE BASE OF THE TOY. IF YOU HAVE BALLS WITHOUT STRING, PUSH THEM OUT BY MEANS OF YOUR PELVIC FLOOR MUSCLES.

CARE

BEFORE USE, BE SURE TO WASH YOUR HANDS WITH WARM WATER AND SOAP AND WIPE DRY. BEFORE THE INSERTING, APPLY A WATER-BASED LUBRICANT TO THE BALLS TO AVOID TEARS AND CRACKS.

STORAGE

KEEP THE TOY OUT OF THE REACH OF CHILDREN IN A SPECIAL BAG (INCLUDED IN THE KIT). REMAINING IN THE BAG, THE TOY IS PROTECTED FROM DIRECT SUNLIGHT, DUST, AND ALSO NOT SUBJECT TO EXTERNAL DAMAGE IN THE FORM OF SCRATCHES AND RUBBING OF THE DEVICE.

MANUAL LOVE STORY

VAGINAL BALLS