

CARE

WASH THE TOY UNDER WARM WATER AND TREAT IT WITH A SPECIAL TOY CLEANER BEFORE AND AFTER EACH APPLICATION.

ALSO, FOR ADDITIONAL DISINFECTION, THE SILICONE VIBRATING RING CAN BE BOILED.

ATTENTION! FOR ANY CONTACT OF THE VIBRATING RING WITH WATER, REMOVE THE VIBRATING ELEMENT FROM THE RING FIRST.

AFTER THE TOY DRIES, APPLY TOY POWDER TO THE MASTURBATOR FOR SEX TOYS. THANKS TO THE POWDER, THE POROUS TEXTURE OF THE MATERIAL WILL RETAIN ITS SOFTNESS AND VELVETY TEXTURE.

STORAGE

KEEP THE TOY OUT OF THE REACH OF CHILDREN, IN A DRY PLACE, PROTECTED FROM DIRECT SUNLIGHT.

STORAGE IN THE ORIGINAL PACKAGING AND PROPER CARE OF THE TOY GUARANTEES ITS DURABILITY.

MANUAL

Satisfaction

USAGE

USING A MASTURBATOR WITH A LUBRICANT WILL MAKE THE PROCESS THE MOST COMFORTABLE AND ENJOYABLE. SATISFACTION MASTURBATORS ARE COMPATIBLE WITH SILICONE, WATER AND GLYCERIN-BASED LUBRICANTS.

BEFORE USING THE VIBRATOR WITH A VIBRATING RING FOR THE FIRST TIME, INSTALL THE LR754 BATTERY (NOT INCLUDED) IN THE VIBRATING ELEMENT OF THE RING, THEN PLACE THE RING ON THE MASTURBATOR.

THE VIBRATING RING CAN ALSO BE USED SEPARATELY FROM THE MASTURBATOR, PLACING IT ON THE BASE OF THE PENIS DURING SOLO STIMULATION OR SEX.

THE LOWER LOCATION OF THE VIBRATION ELEMENT ON THE PENIS WILL STIMULATE THE USER'S SCROTUM.

THE UPPER LOCATION OF THE VIBRATION ELEMENT ON THE PENIS WILL STIMULATE THE USER'S PARTNER CLITORIS.

THE VIBRATION OF THE VIBRATION RING IS SWITCHED ON AND OFF BY MEANS OF A SWITCH LOCATED ON THE SIDE OF THE VIBRATION ELEMENT.