

USAGE

BEFORE USING THE VIBRATING RING, FIRST REMOVE THE FUSE FROM THE VIBRATING BULLET, WHICH IS LOCATED ON THE BATTERY CONTACT UNDER THE UNSCREWING COVER.

BOTH VIBROBULLETS OF PURE PASSION RINGS ASSUME ONE VIBRATION MODE, THE SWITCHING ON AND OFF OF WHICH IS REGULATED BY SIMPLY PRESSING THE BUTTON AT THE BASE OF THE BULLET.

PLACE THE RING ON THE BASE OF THE ERECT PENIS AND UNDER THE SCROTUM AT THE SAME TIME, STRETCHING THE RING AND PUSHING IT ALONG THE PENIS. THE RING SHOULD BE CONVENIENTLY FIXED WITHOUT ROLLING DOWN AND NOT SQUEEZING THE SCROTUM. IF YOU FEEL DISCOMFORT WHILE USING THE COCK RING - IMMEDIATELY STOP FRICTIONS AND REMOVE IT.

IT IS IMPORTANT NOT TO USE THE RING FOR MORE THAN 30 MINUTES TO AVOID CIRCULATORY DISORDERS.

STORAGE

KEEP THE TOY IN A SATIN BAG, OUT OF THE REACH OF CHILDREN. REMAINING IN THE BAG, THE TOY IS PROTECTED FROM DIRECT SUNLIGHT, DUST, AND IS NOT SUBJECT TO EXTERNAL DAMAGE IN THE FORM OF SCRATCHES AND RUBBING OF THE DEVICE.

CARE

BEFORE THE FIRST USE, AS WELL AS BEFORE AND AFTER EACH USE, RINSE THE TOY UNDER A WARM STREAM OF WATER, DRYING WITH A PAPER TOWEL, HAVING PREVIOUSLY REMOVED THE VIBROBULLETS. TREAT THE STIMULATOR WITH A SPECIAL TOY-CLINER FOR ADDITIONAL CARE OR BOIL THE SILICONE RING (AFTER REMOVING THE VIBROBULLETS) FOR ADDITIONAL DISINFECTION.

MANUAL

Pure passion